

# Detachable Product Panel

## Do-it-Your-Self Installation Instructions



### Parts

- 1 - Detachable Product Frame (68160040)
- 1 - Detachable Product Panel(s)
- 4 - Rubber bumpers (32070008)
- 4 - 1-inch screws (38020120)
- 4 - E-Z anchors (38020116)

### Tools

- Cordless drill
- Phillips adaptor for drill
- Square drive adaptor
- 3/16-inch drill bit
- Pencil
- Tape measure



*NOTE: These steps may be altered if you are covering the entire ceiling with Detachable Product Panels. For optimal coverage, it is recommended to do a plan layout prior to mounting any panels.*

**Step 1:** Remove the laced Detachable Product pegboard panel(s) from the frame. (Fig. 1)

**Step 2:** Keeping the existing lace, remove any additional hooks, clips, etc. from the ceiling that will keep the frame from mounting flush to the ceiling.



**Step 3:** Your starting point may vary based on the quantity of Detachable Product Panels purchased. For most set-ups, find the center of the leading edge of the second ceiling panel (behind the cab divider) from the front of your Mobile Tool Store and mark it in both directions. This mark will correspond to the inside edge and the center of your frame. (Fig. 2)



**Step 4:** Using the frame as a template, position the frame with the hinged side as the leading edge towards the front. Hold it tight to the ceiling behind the cab divider and along the center line. Using a 3/16-inch drill bit in a cordless drill, use the four mounting holes located on the inside of the frame as guides and drill through the pegboard ceiling panel. (Fig. 3)

*Note: If you hit wood STOP drilling!*



**Step 5:** Remove the frame from the ceiling position and using a Phillips bit in a cordless drill, screw in an E-Z anchor into each drilled out hole. Tips on E-Z anchor may snap off, but anchor is still good. If there is wood behind the pegboard you do not need to install the E-Z anchor. (Fig. 4)



**Step 6:** Hold the frame tight to the ceiling lining up the mounting holes with the E-Z anchors. Install a rubber bumper and screw into the E-Z anchor. (Fig. 5)

*If there is no anchor present, a rubber bumper and screw through the pegboard and into wood is sufficient.*



**Step 7:** Using the thick lace place hand tool products on the Detachable Product pegboard panel(s) and re-attach the panel to the frame. (Fig. 6)